



EBS01001



## SPECIFICATIONS

## GENERAL SPECIFICATIONS

Item	Standard
<b>Model code</b>	5TG1
<b>Dimensions</b>	
Overall length	1,840 mm (72.4 in)
Overall width	1,170 mm (46.1 in)
Overall height	1,090 mm (42.9 in)
Seat height	800 mm (31.5 in)
Wheelbase	1,280 mm (50.4 in)
Minimum ground clearance	255 mm (10.04 in)
Minimum turning radius	3,500 mm (137.8 in)
<b>Basic weight</b>	
With oil and full fuel tank	169 kg (373 lb)
<b>Engine</b>	
Engine type	Liquid-cooled 4-stroke, DOHC
Cylinder arrangement	Forward-inclined single cylinder
Displacement	439 cm <sup>3</sup> (26.79 cu in)
Bore × stroke	95.0 × 62.0 mm (3.74 × 2.44 in)
Compression ratio	11.9:1
Starting system	Electric starter
<b>Lubrication system</b>	Dry sump
<b>Oil type or grade</b>	
Engine oil	API service SE, SF, SG type or higher
<p>The chart shows temperature ranges in Fahrenheit (top) and Celsius (bottom). SAE 5W30 is recommended for temperatures down to -20°F (-28°C). YAMALUBE4 (10W30) or SAE 10W30 is recommended for temperatures from 0°F (-18°C) to 110°F (43°C). YAMALUBE4 (20W40) or SAE 20W40 is recommended for temperatures from 30°F (-1°C) to 130°F (54°C).</p>	
<b>Oil capacity</b>	
Engine oil	
Periodic oil change	1.75 L (1.54 Imp qt, 1.85 US qt)
With oil filter replacement	1.85 L (1.63 Imp qt, 1.96 US qt)
Total amount	1.95 L (1.72 Imp qt, 2.06 US qt)
<b>Radiator capacity (including all routes)</b>	1.3 L (1.14 Imp qt, 1.37 US qt)
<b>Air filter</b>	Wet type element
<b>Fuel</b>	
Type	Premium unleaded gasoline only
Fuel tank capacity	10.0 L (2.20 Imp gal, 2.64 US gal)
Fuel reserve amount	1.9 L (0.42 Imp gal, 0.50 US gal)



## CHECKING THE ENGINE OIL LEVEL



### 3. Check:

- engine oil level

Oil level should be between the minimum level mark (a) and the maximum level mark (b).

Low oil level → Add oil to the proper level.

### NOTE:

- Wait a few minutes until the oil settles before checking the oil level.
- Do not screw the dipstick (1) in when checking the oil level.



**Recommended oil**  
Follow the chart on the left.

### NOTE:

Recommended oil classification:

API Service "SE", "SF", "SG" type or equivalent (e.g. "SF—SE—CC", "SF—SE—SD" etc.)

### CAUTION:

- Do not add any chemical additives. Engine oil also lubricates the clutch and additives could cause clutch slippage.
- Do not allow foreign material to enter the crankcase.

4. Start the engine, warm it up for several minutes, and then turn it off.

### 5. Check:

- engine oil level

### NOTE:

Before checking the engine oil level, wait a few minutes until the oil has settled.